	The New Standard of Level		
Quest tec	The New Standard of Level		
	Glass-Trac Level-Trac		
SOLUTIONS	Steam-Trac Magne-Trac		
ТО	SUBJECT GLASS COVER REMOVAL		
	(PERFORATED CUSHION INSERT DATE 11/16/2012		
	ISSUE NO. 2012-A		
	BY JAB		
Note: This document is not the instruction manual. The instruction entirety prior to installation of equipment.	on manual should be reviewed in its		
1) Check the bolt torque by following the retorque procedure	on the torque tag, and instruction manual.		
TO TORQUE GAGE FOLLOW ASSEMBLING SEQUED TIGHTEN IN 4-5 FT. LB. STEP BOLT TIGHTENING SEQUEN ©13 ©9 ©5 ©1 ©3 ©7 ©11 ©14 ©10 ©6 ©2 ©4 ©8 ©12 GAGE SERIES TORQUE L-Low Pressure 20 Ft. Lb. Tota M-Mid Pressure 32 Ft. Lb. Tota H-High Pressure 40 Ft. Lb. Tota			
2) Review the yellow caution tape, then remove from gage.			
QUEST-TEC SOLUTIONS • 13960 S. WAYSID SALES@QTSLEVEL.C			
WWW.QTSLEVEL.COM • TEL:			

1 OF 2

Quest tec		The New Standard of Level					
GUESLEC			Glass-	Trac	Level-Trac		
	SOLUTION		Steam-Trac Magne-Trac				
	TO		SUBJECT		OVER REMOVAL RATED CUSHION INSERT)		
			DATE	11/16/201	12		
			ISSUE NO.	2012-A			
			BY	JAB			
3)	Under the yellow caution tape, there is a perforated cushion. This part protects the glass from dirt, dust and debris until the gage is ready to be placed in service.						
	b. Pra.			1PC)			



4) Pry up one edge, and remove the perforated insert to expose the glass.



QUEST-TEC SOLUTIONS • 13960 S. WAYSIDE DR HOUSTON, TX 77048 SALES@QTSLEVEL.COM WWW.QTSLEVEL.COM • TEL: 281-240-2440